











Delay bypass mode set jumper

JP1 Setting	Mode
1-2	Delay enabled
2-3	Delay disabled

Phase Invert jumper (No jumper installed => phase 180 deg)